

Hoist Replacement Parts



Description	For Use With	Mfr. Model	Item No.	\$ Each
Steel Top Hook Assy	3Z952-3Z956	14J26	2ZE70	426.00
Steel Top Hook Assy	4ZX63, 4ZX70, 4ZW68, 4ZW73, & 4ZW74	40605	2ZE72	134.40
Steel Top Hook Assy	4ZX62, 4ZX67, 4ZX68, 4ZX69, 4ZW67, & 4ZW72	40603	2ZE73	74.45
Steel Top Hook Assy	4ZW93	45604	2ZE74	117.40
Steel Top Hook Assy	4ZX61, 4ZX64-4ZX66, 4ZW66, 4ZW69, & 4ZW70	40601	2ZE75	62.95
Steel Top Hook Assy	5Z382, 5Z383, 5Z384, 5Z389, 5Z390, 4ZW62, & 4ZW63	28689	2ZE76	49.10
Steel Top Hook Assy	5W557, 5W558, & 2Z896	22807	2ZE77	74.45
Steel Top Hook Assy	5Z387, 5Z388, 5Z393, 5Z394, 4ZW77, & 4ZW78	35616	2ZE78	84.75
Steel Top Hook Assy	4ZW92	45602	2ZE79	71.15
Steel Top Hook Assy	4ZW55, 4ZW60, & 5W561	22836	2ZE80	128.50
Steel Top Hook Assy	5W559, 5W560, & 2Z897	22830	2ZE81	97.65
Steel Top Hook Assy	5W556, 2Z895, & 4ZW61	22923	2ZE82	69.25
Steel Top Hook Assy	4ZX61, 4ZX64, 4ZX65, & 4ZX66	73606	2ZE83	127.70
Steel Top Hook Assy	4ZW91	45601	2ZE84	57.50
Steel Top Hook Assy	2Z782, 6W005, & 6W006	IRB5048U	2ZE85	97.85
Steel Top Hook Assy	4Z999, 6W009, & 6W010	NRB5048U	2ZE86	295.00
Steel Top Hook Assy	4ZX69, 4ZX62, 4ZX67, & 4ZX68	73607	2ZE87	155.25
Steel Top Hook Assy	2Z783, 6W007, & 6W008	KRB5048U	2ZE88	144.30
Lower Hook Block	3YA91	230137	2ZE89	12.93
Steel Top Hook Assy	4UV26-4UV31, 4ZW42, 4ZW44, 4ZW48, 4ZW51, 3DY11, & 3DY12	20650B	2ZE90	29.45
Steel Top Hook Assy	5Z385, 5Z386, 5Z391, 5Z392, 4ZW75, & 4ZW76	35617	2ZE96	81.80
Steel Top Hook Assy	3KP87, 4ZX86, & 4ZX87	36613B	2ZE98	106.90
Steel Top Hook Assy	5UT28, 5UT29, & 5UT30	400272	2ZJ10	74.45
Steel Top Hook Assy	5UT31, 5UT32, & 5UT33	400281	2ZJ12	97.65
Steel Bottom Hook Assy	3YB72-3YB76, 3YB78-3YB80, 3YB83-3YB86, 3YB90-3YB99, 3YE10-3YE12, & 3YE16-3YE18	3JG20S	2ZE71	113.00
Steel Bottom Hook Assy	5W556, 2Z895, & 4ZW61	22787	2ZE91	69.25
Steel Bottom Hook Assy	5W557, 5W558, & 2Z896	22808	2ZE92	74.00
Steel Bottom Hook Assy	5W559, 5W560, & 2Z897	22831	2ZE93	97.65
Steel Bottom Hook Assy	4ZX63, 4ZX70, 4ZW68, 4ZW73, & 4ZW74	40606	2ZE94	134.40
Steel Bottom Hook Assy	4ZX62, 4ZX67, 4ZX68, 4ZX69, 4ZW67, & 4ZW72	40604	2ZE95	70.25
Steel Bottom Hook Assy	4ZX61, 4ZX64-4ZX66, 4ZW66, 4ZW69, & 4ZW70	40602	2ZE97	61.95
Steel Bottom Hook Assy	5Z385, 5Z386, 5Z391, 5Z392, 4ZW75, & 4ZW76	35611	2ZE99	90.75
Steel Bottom Hook Assy	4ZW55, 4ZW60, & 5W561	22844	2ZJ11	144.35
Steel Bottom Hook Assy	4ZW93	45603	2ZJ13	117.40
Lower Latch Hook	5Z387, 5Z388, 5Z393, 5Z394, 4ZW77, & 4ZW78	35645	2ZJ14	143.05
Steel Bottom Hook Assy	3KP87, 4ZX86, & 4ZX87	36606	2ZJ15	200.75
Lower Latch Hook	5Z387, 5Z388, 5Z393, 5Z394, 4ZW77, & 4ZW78	35612	2ZJ16	103.20
Steel Bottom Hook Assy	2Z782, 6W005, & 6W006	IRB5053U	2ZJ17	99.10
Steel Bottom Hook Assy	4Z999, 6W009, & 6W010	NRB5053U	2ZJ18	300.00
Steel Bottom Hook Assy	2Z783, 6W007, & 6W008	KRB5053U	2ZJ19	146.50
Lower Latch Hook	4UV26-4UV31, 4ZW42, 4ZW44, 4ZW48, & 4ZW51	23030B	2ZJ20	27.65
Lower Latch Hook	5Z382, 5Z383, 5Z384, 5Z389, 5Z390, 4ZW62, & 4ZW63	28686B	2ZJ21	60.50
Lower Latch Hook	5Z382, 5Z383, 5Z384, 5Z389, 5Z390, 4ZW62, & 4ZW63	28683B	2ZJ22	244.25
Lower Latch Hook	5UT31, 5UT32, & 5UT33	400309	2ZJ23	97.65
Steel Bottom Hook Assy	5Z385, 5Z386, 5Z391, 5Z392, 4ZW75, 4ZW76, 4Z401, & 5Z140	35651B	2ZJ24	260.75
Hook Safety Latch Kit	3Z952-3Z955	H7540	2ZJ25	7.51
Hook Safety Latch Kit	#4 CM Hoist Hooks	45661	2ZJ26	10.87
Hook Safety Latch Kit	#6-7 CM Hoist Hooks	45663	2ZJ27	13.48
Hook Safety Latch Kit	#5 CM Hoist Hooks	45662	2ZJ28	10.87
Hook Safety Latch Kit	2Z782, 6W005, & 6W006	JHH5074T	2ZJ29	8.21
Hook Safety Latch Kit	2Z783, 4Z999, 6W007- 6W010	KHH5074T	2ZJ30	10.46
Hook Safety Latch Kit	5W557, 5W558, & 2Z896	22929	2ZJ31	12.22
Hook Safety Latch Kit	5W559, 5W560, & 2Z897	22930	2ZJ32	14.54
Hook Safety Latch Kit	5W556, 2Z895, & 4ZW61	22928	2ZJ33	12.22
Hook Safety Latch Kit	4ZW55, 4ZW60, & 5W561	22933	2ZJ34	39.10
Hook Safety Latch Kit	Various CM Hoists	595522	2ZJ39	6.71
Hook Safety Latch Kit	5UT28, 5UT29, & 5UT30	400450	2ZJ35	10.46
Hook Safety Latch Kit	5UT25, 5UT26, & 5UT27	400449	2ZJ36	8.59
Hook Safety Latch Kit	3YA91	230168	2ZJ37	5.70
Hook Safety Latch Kit	5UT31, 5UT32, & 5UT33	400451	2ZJ38	14.54
Push Button Control	2YE29-2YE46	534K97B	2ZJ40	187.75
Push Button Control	5Z382-5Z394, 4ZW62, 4ZW63, 4ZW75-4ZW78, 3KP84-3KP87, 4ZX86, 4ZX87, 4Z399-4Z401, 5Z137-5Z143, 3Z844, & 3Z845	28464	2ZJ41	126.55
Push Button Control	5Z382-5Z388, 4Z399-4Z401, 3Z844, & 3Z845	20607	2ZJ42	303.75