

Motor to Ventilator Cross Reference

Motor	Ventilator (Used In)				Motor	Ventilator (Used In)						Motor	Ventilator (Used In)			
Belt Drive					Direct Drive							Direct Drive - Continued				
1AGF8	2RB53	—	—	—	4YU19	4YC70	4YC72	4HZ44	4HZ48	4HZ46	4HZ50	4YU34	4YC66	4YC68	4YC67	—
1AGF9	2RB86	—	—	—	4YU20	4HZ52	4HZ54	—	—	—	—	4YY54	4YC73	4HZ49	4HZ51	—
1AGG1	1MBE6	2RB59	2RB60	2RB61	4YU21	4YC76	—	—	—	—	—	4YY55	4YC77	4HZ53	4HZ55	—
1AGG2	1MBE7	2RB62	—	—	4YU22	4HZ56	4HZ58	—	—	—	—	4YY56	4YC86	—	—	—
1AGG3	1MBE8	2RB63	—	—	4YU23	4HZ36	4HZ40	4HZ38	4HZ42	—	—	5BE52	4YC88	4YC92	4YC91	4YC93
4YU30	1MBE9	5PV07	2TE33	—	4YU24	4YY75	—	—	—	—	—	5BE54	4YC90	4YC49	4YC94	4YC56
4YU35	5PV06	—	—	—	4YU26	4HZ57	4HZ59	—	—	—	—	5BE56	4YC57	4YC58	—	—
4YU38	3GY66	—	—	—	4YU27	4YC69	4HZ37	4HZ41	4HZ39	4HZ43	2RB87	5BE58	4YC51	4YC59	—	—
4YU39	3GY67	—	—	—	4YU28	4YC71	—	—	—	—	—	5BE60	4YC53	4YC61	—	—
4YU40	3GY68	3GY73	—	—	4YU29	4HZ45	4HZ47	—	—	—	—	5BE62	4YC87	4YC89	4YC48	—
4YU41	3GY69	3GY74	2TE35	—	4YU31	3GY71	5PV08	2TE34	—	—	—	5BE64	4YC50	—	—	—
					4YU32	4HZ32	4HZ34	4YC64	—	—	—	5BE66	4YC52	4YC54	4YC60	4YC62
					4YU33	3GY70	4HZ33	4HZ35	4YC65	—	—	5BE68	4YC55	4YC63	—	—